

cuckoolandTM.com
LIVE IN THE WOW




Harry High Rise

Assembly Instructions

Model : MG 7733

Product Size : 920mm x 1930mm (Base Int Size)

Thank you for purchasing this product. Before starting assembly we suggest you spend a short time reading through this leaflet, then follow the simple step by step guide. Two people are needed to assemble this product.



Model : MG 7733

Product Size : 920mm x 1930mm (Base Int Size)

TOP TIPS BEFORE YOU START !

1. Please check that all parts & hardware are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, Please identify all the parts required for that step.
3. We recommend that where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
4. For the protection of your furniture, particularly items of high gloss finish, we recommend that the product is placed on a Protected surface during assembly to prevent any damage.
5. During assembly please take care not to over-tighten any fittings, as this may damage the product.

IMPORTANT - READ CAREFULLY - RETAIN FOR FUTURE REFERENCE

CARE AND MAINTENANCE OF YOUR FURNITURE

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g hot drinks) directly on the wood surface.
- Please do not drag or pull your furniture.

IMPORTANT INFORMATION

1. Thickness of mattress should not exceed 184mm.
2. Children should be discouraged from playing on top of this bunk bed.
3. The bunk bed should be checked periodically by the owner to ensure that the guardrail, ladder, and other components are maintained in the correct position and state of repair and that all connectors are tight.
4. A bunk bed is not to be placed near a ceiling fan unless the distance between the closest points on the ceiling fan bunk Bed is at least 2 metres.
5. Use guardrails on both sides of upper bunk.
6. Prohibit horseplay on or under bed(s).
7. Prohibit more than one person on upper bunk.
8. Use Ladder for entering and leaving upper bunk.
9. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against The wall to prevent entrapment between the bed and the wall.
10. **WARNING** Do not use the bunk bed/high bed if any structural part is broken or missing.
11. Ventilation of the room is necessary in order to keep the humidity low and to prevent mould in and around the bed.
12. **WARNING** "high beds & the upper bed of bunk beds are not suitable for children under six years due to risk of injury from falls";
13. **WARNING** "children can become trapped between the bed & the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g.cupboard) and the like. To avoid risk of serious injury the distance between the top safety barrier and the adjoining structure shall not exceed 75mm nor shall be more than 230mm"
14. always follow the manufacturer's instruction;
15. Recommended Mattress Size : 90cm x 190cm (UK Single) with Maximum Depth of 18.4cm
16. This item conforms to European Safety Standards - BS EN 747-1 : 2012 + A1 : 2015 & BS EN 747-2 : 2012 + A1 : 2015
17. **WARNING** "Bunk beds and high beds can present a serious risk of injury from strangulation if not used correctly. Never attach or hang items to any part of the bunk bed that are not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts and bags"
18. High beds and the upper bed of bunk beds is suitable for a maximum mattress thickness of 184mm. The top of mattress must not come above the line marked on the bed.

STRANGULATION HAZARD:


19. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed for example, but not limited to hook, belt and jump ropes.

Guide To Assembly


Model : MG 7733

Tools Required For Assembly


Phillips Screw Driver



DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT. USE OF POWER TOOLS WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




Approximately 3 hour








2 People Required

Rubber Hammer



Tape Measure




Part List

Model : MG 7733

Carton 1 of 5			Carton 4 of 5		
No.	Part Name	Pcs	No.	Part Name	Pcs
01	Plinth Panel (Wardrobe)	1	08	Back Panel (Right)	1
02	Bottom Panel (Wardrobe)	1	19	Back Panel	1
03	Support Panel (Wardrobe)	1	21	Top Panel (Desk)	1
12	Bottom Panel (Ladder)	1	41	Wire Mesh Frame	1
13	Left Panel (1st Step Ladder)	1	42	Ladder Support Rail	5
14	Right Panel (1st Step Ladder)	1	44	Hanging Rail	1
15	Back Panel	1		LVL Slats	15
16	Top Panel (1st Step Ladder)	1	Carton 5 of 5		
20	Support Panel	1			
32	Back Panel (Drawer)	1	17	Left Panel (Desk)	1
33	Left Panel (Drawer)	1	22	Back Panel (Ladder)	1
34	Right Panel (Drawer)	1	23	2nd Ladder Step	1
35	Bottom Panel (Drawer)	1	24	3rd Ladder Step	1
36	Front Panel (Drawer)	1	25	4th Ladder Step	1
37	Support Panel (Drawer)	1	26	Left Ladder Panel	1
Assembly Instructions + Fitting List			27	Right Ladder Panel	1
			31	Side Panel (Left)	1
Carton 2 of 5					
04	Right End Panel (Back)	1			
06	Left Panel (Wardrobe)	1			
07	Support Panel (Wardrobe)	2			
10	Right End Panel (Front)	1			
Carton 3 of 5					
05	Back Panel (Wardrobe)	1			
18	Back Panel (Left)	1			
28	Side Front Panel	1			
29	Side Front Panel (Upper)	1			
30	Side Panel (Back)	1			
38	Back Side Rail	1			
39	Front Side Rail	1			
43	Support Rail	1			

Part List

Model : MG 7733


























Fitting List

Model : MG 7733

Carton 1 of 5

Fitting List

No.	Part Name		Pcs
A	Cam Stud (small)		41
B	Cam		46
C	M8 x 25mm Wood Dowel		95
D	Contractfix Dowel		5
E	38mm Chipboard Screw		6
F	22mm Chipboard Screw		4
G	14mm Chipboard Screw		10
H	14" Drawer Slide (SJ)		1 set
J	M6 x 13mm Baller		21
K	M6 x 25mm Allen Bolt		2
L	M6 x 30mm Allen Bolt		30
M	M6 x 35mm Allen Bolt		13
N	M6 x 40mm Allen Bolt		5
P	M6 x 50mm Allen Bolt		23
Q	M6 x 60mm Allen Bolt		8
R	M6 Round Nut		10
S	M6 JCN Nut		9
T	M6 Allen Wrench		2
U	M5 x 40 JCBCW Screw		17
V	PVC Back Support		4
W	PVC Hanging Hook		2
X	Felt Pads (45 x 14mm)		16
Y	Sticker (25mm)		26+2

Caution

There are many small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit. As an extra precaution, screw cover caps should be permanently fixed in position. (Where applicable)

USEFUL HINTS & TIPS


Two people will be required to assemble this unit

Please keep this assembly instruction for future reference

Guide To Assembly

Model : MG 7733

1



A x 2





B x 19



C x 34

WHEN FITTING CAMS

ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



Guide To Assembly

Model : MG 7733

2




A x 14



B x 4



C x 4



D x 3





J x 3



W x 2

WHEN FITTING CAMS

ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7733


3




U x 2




4



5







6



Guide To Assembly


Model : MG 7733



Guide To Assembly

Model : MG 7733


11




12




X x 4



13



K x 2




Guide To Assembly

Model : MG 7733


14




R x 2




P x 2



15




C x 8




Guide To Assembly

Model : MG 7733


16



17



18



Guide To Assembly

Model : MG 7733

19



A x 8



B x 8



C x 18





D x 2



J x 2

WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7733


20




21



22



23




Guide To Assembly

Model : MG 7733

24





G x 3



H x 1


To Assembly the Drawer Slide, Please Follow Step as Below



25





G x 3



H x 1


To Assembly the Drawer Slide, Please Follow Step as Below



Guide To Assembly

Model : MG 7733


26



A x 4





B x 8



C x 20

WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7733


27




28



29




30





Guide To Assembly

Model : MG 7733


31  A x 2





32




33  U x 5



34  A x 1

 X x 6



Guide To Assembly

Model : MG 7733


35



A x 2





B x 4




C x 5

WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



36




A x 1



Guide To Assembly

Model : MG 7733


37



38




M x 2



Guide To Assembly

Model : MG 7733


39



40




U x 5



Guide To Assembly



Model : MG 7733

41



J x 4


Q x 4



42




M x 10



Guide To Assembly

Model : MG 7733


43



44





U x 1



Guide To Assembly

Model : MG 7733

45



Guide To Assembly

Model : MG 7733


46



P x 4



R x 4




47




M x 1



P x 4




S x 5



Guide To Assembly

Model : MG 7733

48




49



N x 5




S x 3



Guide To Assembly



Model : MG 7733

50




J x 4

P x 4





51



J x 2

Q x 2




Guide To Assembly

Model : MG 7733


52



J x 2



Q x 2




53



J x 2



P x 2




Guide To Assembly

Model : MG 7733



54



J x 2



P x 2





55



P x 1



S x 1




Guide To Assembly

Model : MG 7733

56



L x 30



Guide To Assembly

Model : MG 7733


57



F x 4




V x 4



Guide To Assembly

Model : MG 7733


58



A x 3





B x 3



C x 6


WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7733


59  E x 4




60  E x 2



61




62



63  G x 4


 H x 1 set



Guide To Assembly


Model : MG 7733

64



65

○ Y x 12



66

○ Y x 14

