




The cot is now complete, please read the user guide notes to maintain the unit to its highest standard.

USER GUIDE

Thank you for choosing a KIDSAW product. Please take a little time to read the important safety notes detailed below. This will ensure many years of happy, safe use.

WARNING:

- Recommended mattress size 120 x 60cm for cot bed. The maximum thickness of the mattress is 10cm.
- Do not leave anything in cot or place the cot close to another product, which will provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blind/certain cords.
- The safety of the cot could be adversely affected by fitting flammable drapes.
- The cot should not be used if any parts are lost or damaged.
- Only use spare parts approved by the manufacturer.
- Be aware of the risk of open fires and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the cot.
- Recommended mattress size 170 x 60cm for Junior bed. The maximum thickness of the mattress is 10cm.
- The thickness of the mattress used shall be such that the internal height (surface of the mattress to the upper edge of the cot frame) is at least 500mm in the lowest position of the mattress top and at least 200mm in the highest position of the mattress top.
- All assembly fittings should always be tightened properly and care should be taken that no screws are loose, because a child could trap parts of the body, or clothing (e.g. strings, necklaces, ribbons for babies' dummies), which could pose a risk of suffocation and strangulation.
- Do not leave anything in the cot which could provide a foothold for the child to climb out or present a danger of suffocation or strangulation.
- Remove all items from within the cot before dismantling.
- Adult assembly required.
- Do not use more than one mattress in the cot.
- A statement about the minimum size of mattress to be used with the cot. The dimension shall take into account that there shall be no gap more than 30mm between the mattress and the sides and ends in any position of the mattress. A statement to prevent injury from falls that when the child is able to climb out of the cot, the cot shall no longer be used for that child.

CARE & MAINTENANCE


Wipe clean with sterile wipes or damp cloth.

**IMPORTANT
KEEP FOR FUTURE REFERENCE & READ CAREFULLY**

COTBED 1200 WHITE

Follow us on
facebook 

www.facebook.com/kidsaw



INSTRUCTIONS

KIDSAW®
MAKES FURNITURE CHILDS' PLAY

Kidsaw Ltd
PO Box 10959, Leicester, LE41 9LU
Tel: +44 (0)116 2519551 Email: support@kidsaw.co.uk
www.kidsaw.co.uk

Safety instructions



WARNING!

- Risk of injury! Improper assembly or use of the product may result in injury.
- This product is suitable for children aged between 0–4 years.
- WARNING: Do not place the product near heat sources, windows or other furniture.
- WARNING: Do not use the product if any part is broken, torn or missing.
- As the product requires self-assembly there is a risk of building it in an unsafe manner. Ensure that great care is taken during the assembly of this product.
- The product is for use for 1 child at a time.
- All assembly fittings should be tightened properly and checked regularly to ensure that no screws are loose and re-tightened as required.
- Loose screws or fittings could trap parts of the body or clothing (e.g. ribbons, drawstrings, necklaces). This could pose a risk of strangulation.
- Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords, and should be placed either tight to any wall or have a gap of 300 mm between the wall and the side of the bed.
- WARNING: Do not leave anything in the cot bed or place the cot bed close to another product, which could provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords.
- WARNING: Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires etc in the near vicinity of the product.
- WARNING: Do not use more than one mattress in the cot bed. There is a risk of suffocation.
- WARNING: The height of the cot base is adjustable. The lowest position is the safest and the base should always be used in that position as soon as the baby is old enough to sit up.
- WARNING: Thickness of the mattress shall be such that the internal height (surface of the mattress to the upper edge of the cot frame) is at least 500 mm in the lowest position of the cot base and at least 200 mm in the highest position of the cot base.
- WARNING: When a child is able to climb out of the cot bed, the cot bed shall no longer be used for that child to prevent injury from falls.
- WARNING: An excessive gap between mattress and any side of the cot bed (> 30 mm) can lead to an entrapment or suffocation hazard.
- Do not use power tools such as drills and power drivers, as this may damage the frames or fittings. Only use hand screwdrivers.
- Do not modify or alter the product in any way.
- Lift the product when moving along the floor, do not drag as this can cause damage.
- During assembly children should be kept away from the product due to possible risk of injury. Bolts and other small parts are included. They may cause choking if swallowed or inhaled.
- Make sure that the product is properly placed on solid, stable and level ground. Do not place the product on a slope.
- The cot bed conforms to BS EN716-1:2017. The child's bed conforms to BS 8509:2008 +A1:2011.




Safety instructions for Changing Unit

WARNING!


- Risk of injury! Improper assembly or use of the product may result in injury.
- This changing unit is suitable for children aged between 0–12 months.
- Babies must be supervised at all times when using a changing mat on a dresser or other raised surfaces.
- The changing unit must be fixed to the wall for safe use of the product.
- This product is suitable for use by a child with a maximum weight of 11 kg.
- WARNING: In order to prevent overturning the changing unit must be used with the wall attachment device provided. Serious or fatal crushing injuries can occur from furniture tipping over.
- Do not let children climb or hang on drawers or shelves.
- Place the heaviest items in the lower drawers or shelves.
- Do not place TV's or other heavy objects on top of the product.
- Never open more than one drawer at a time
- An attachment device is provided with your product. However, you will need to source suitable fixings for your wall type. If in doubt, consult a qualified tradesperson.
- Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.
- All assembly fittings should always be correctly tightened and checked regularly.
- WARNING: Do not leave the child unattended when using the product.
- Only use the product for its intended purpose.
- Only competent adults may set up the product.
- Make sure that children do not play with the plastic wrapping. They may get caught in it when playing and suffocate.
- Keep children away during the assembly of the product. Bolts and other small parts are included. They may cause choking if swallowed or inhaled.
- Make sure that the product is stable before use. The safety of the product can only be ensured if it has been properly assembled and all connections have been made securely. ? Regularly check all connections to ensure that they are properly tightened.
- Do not use this product or attempt to assemble it if any components are missing or damaged.
- The product fits changing mats of approximately 78 × 42 cm.
- Make sure that the product is properly placed on solid, stable and level ground.
- Do not place the product on a slope.
- Do not use the product as a climbing aid or tread. Do not sit or stand on the product.
- Never place the product under windows. Children may use it as a step and fall through the window.
- The changing unit conforms to BS EN 12221:2008+A1:2013




A	50	B	58	C	30	D	34	E	4
									
F	36	G	6	H	36	I	6	J	6
									
K	8	L	4	M	6	N	8	O	6
									
P	1	Q	5	R	5	S	8	T	16
									




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11




STEP 12




STEP 13




STEP 14




STEP 15




STEP 16




STEP 13




STEP 14




STEP 15




STEP 16



STEP 17




STEP 18



The product allows the beams to be assembled at 3 different heights. Select one of the assembly positions for the beams .

NOTE: The lowest position is the safest and should always be used in that position as soon as the baby is old enough to sit up.

STEP 19



STEP 20

