
DO NOT DRAG
2 MAN LIFT

Ellesmere



Wardrobe

Assembly instruction

















IMPORTANT: RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY IND. 4022551

BEFOR ASSEMBLY


MAIN COMPONENTS

-unpack all the parts and identyfy them against the fitting and components list.
-do not discard any packaging untill you have checked that you have all parts as shown below.
-you may find the construction of your dresser easier if you have the help of another person.
-crosshead screwdriver (not provided).



1000806  x 1	1005857  x 48	1004831  x 4
1005367  x 44	1006091  x 44	1001262  x 8
1006012  (3 x 16) x 47	1000893  x 1	1000225  x 4
1004785  x 6	1104028  x 6	1005836  x 4
1002152  x 1	1005681  (4 x 16) x 12	1110778  (6 x 25) x 4
1133253  x 3	1006031  (4 x 22) x 6	1000222  x 2


ARTIKELNUMMER ITEM NUMER ARTIKELNUMMER	BOX	4022551	AANTAL QUANTITY ANZAHL	AFTMETINGEN [mm] DIMENSIONS [mm] ABMESSUNGEN [mm]		
1	4/4	2226527	1	1724	70	16
2	4/4	2226528	1	1724	70	16
3	4/4	2226530	1	1777	69	16
4	4/4	2226529	1	1777	69	16
5	3/4	2226522	1	1757	488	16
6	3/4	2226523	1	1757	488	16
7	2/4	2226525	1	858	70	16
8	2/4	2226533	1	858	501	16
9	2/4	2226532	1	858	500	16
10	1/4	2226526	1	998	70	16
11	1/4	2226534	1	997	504	16
12	4/4	2225627	1	1715	880	2,5
13	2/4	2226531	2	858	500	16
14	1/4	2226499	1	400	180	16
15	1/4	2226500	1	400	180	16
16	1/4	2226510	1	801	159	16
17	1/4	2226501	1	853	260	16
18	1/4	2226453	1	814	405	2,5
19	4/4	2226524	2	1363	425	16



EN. In case of complaim please advise the spare part number.


1

1005857	1004831	1006091
x 4	x 2	x 8



2

1005857	1004831	1006091
x 4	x 2	x 8




3

1005857 x 8


1005367 x 11

1006091 x 6


1004785 x 3



4




5




6


1005857	1005367	1006091	1004785
x 8	x 11	x 6	x 3



7




8





9

1005857 x 4




1006091 x 3







10

1005857 x 8




1005367 x 9






11




12


1005857	x 4	1005367	x 6




13




14






15


1005857 x 4




1005367 x 3




1006091 x 6







16



17




18




19


1006012




(3 x 16)

x 40






20




21


1001262



x 8




22





23

1000225 x 4



1110778 (6 x 25) x 4






24

1000222 x 2






25


1005857 x 4

1005367 x 4




26

1005836 x 4




27


1006091




x 4



28




29




30


1006012



(3 x 16)

x 5






31

1002152 x 1


1006012 (3 x 16) x 2



32


1125002 x 1

1006031 (4 x 22) x 2




33






34

1005681




(4 x 16) **x 12**

1104028





x 6





x 2

35











36

1133253




x 2

1006031



(4 x 22) x 4




37


1000893




x 1




38



39



40


kg
max 15 kg / 33 lb
kg
max 15 kg / 33 lb
kg
max 15 kg / 33 lb
kg
max 15 kg / 33 lb

Safety

Always use the wall attachment strap provided.
All assembly fixings should always be tightened properly. Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc.) which could pose a risk of strangulation.
Be aware of the risks of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the wardrobe.
Do not use if any of the parts are broken, torn or missing.
Any additional or replacement parts can only be obtained from the manufacturer or the distributor.
ensure there are no small parts fittings are left after assembly as these can be a chocking hazard.

Maintenance

Take care when handling or moving the furniture. Careless handling may cause damage.
Regularly check that all fixings are tightened and that there are no broken or damaged parts.

Cleaning

Your wardrobe can be cleaned by wiping with a damp cloth and drying with a soft clean cloth. Do not use abrasives, bleach, alcohol or ammonia based household polishes.

Little Acorns
01952460696 and address:
The Malthouse,
Sheriffhales,Shifnal.
Shropshire TF11 8RD