

DO NOT DRAG
2 MAN LIFT

Traditional Sleigh



Wardrobe

Assembly instruction















IMPORTANT: RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY IND. 4021018

BEFOR ASSEMBLY


MAIN COMPONENTS

-unpack all the parts and identyfy them against the fitting and components list.
-do not discard any packaging untill you have checked that you have all parts as shown below.
-you may find the construction of your dresser easier if you have the help of another person.
-crosshead screwdriver (not provided).



1005681  (4 x 16) **x 12**	1005857  **x 24**	1000868  **x 4**
1005367  **x 26**	1006091  **x 26**	1001262  **x 8**
1006012  (3 x 16) **x 32**	1000893  **x 1**	1000225  **x 4**
1004785  **x 6**	1104028  **x 6**	1110778  (6 x 25) **x 4**
1005471  (4 x 25) **x 2**	1005865  **x 2**	

ARTIKELNUMMER ITEM NUMER ARTIKELNUMMER	BOX	4021018	AANTAL QUANTITY ANZAHL	AFTMETINGEN [mm] DIMENSIONS [mm] ABMESSUNGEN [mm]		
1	1/3	2217314	2	782	500	16
2	3/3	2217317	1	920	70	16
3	2/3	2217315	1	1743	504	16
4	2/3	2217316	1	1743	504	16
5	3/3	2217319	1	1724	70	16
6	3/3	2217320	1	1724	70	16
7	3/3	2217318	1	780	70	16
8	3/3	2217322	1	1584	387	16
9	3/3	2208766	1	1626	804	2,5
10	1/3	2217321	2	782	496	16
11	3/3	1120135	2	767	-	-




EN. In case of complaim please advise the spare part number.

WARNING!

To avoid risk of injury assembly must be carried out in accordance with the instructions.

1

1005857 x 8	1000868 x 4	1006091 x 12
	1004785 x 6	1005367 x 10



2

1005367 x 16

1005857 x 8

1 x 2

3

x 6

1

4

3


1

x 6


4

1005857 x 8


1006091 x 14




5




6



7




8




9


1001262



x 8



10




11


1006012





(3 x 16) **x 32**




12








13




14

1005681 (4 x 16) **x 12**

1104028 **x 6**




15





16

1005865 x 2



1005471 (4 x 25) x 2






17

1000893 x 1







WARNING!

In order to prevent overturning this product must be used with the wall attachment strap provided.


18



19



20



Safety

Always use the wall attachment strap provided.
All assembly fixings should always be tightened properly. Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc.) which could pose a risk of strangulation.
Be aware of the risks of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the wardrobe.
Do not use if any of the parts are broken, torn or missing.
Any additional or replacement parts can only be obtained from the manufacturer or the distributor.
ensure there are no small parts fittings are left after assembly as these can be a chocking hazard.

Maintenance

Take care when handling or moving the furniture. Careless handling may cause damage.
Regularly check that all fixings are tightened and that there are no broken or damaged parts.

Cleaning

Your wardrobe can be cleaned by wiping with a damp cloth and drying with a soft clean cloth. Do not use abrasives, bleach, alcohol or ammonia based household polishes.

Little Acorns
01952460696 and address:
The Malthouse,
Sheriffhales,Shifnal.
Shropshire TF11 8RD