


DOUBLE / KING SIZE



Important Information

- We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
- Carefully check that you have all the parts before beginning assembly.
- Keep fittings out of children's reach and keep children well away from construction area.




An instructional video of the operation of the Ottoman Lift Up System is available via YouTube using the following address: https://youtu.be/hyq4zm7h_yU

Warning

- You must ensure that the mattress is on the bed frame before operating the lift mechanism, failure to do so could result in injury.
- Keep hands clear of the mechanism when opening or closing the ottoman.
- Beware of entrapment – Never reach in through the mechanism to access the storage area.
- Always be sure that the ottoman is FULLY opened before accessing the storage area.
- Do not exceed the maximum weight as specified in the table below:

Bed	BedSize	Min Weight (kg)	Max Weight (kg)
STILLE OTTOMAN BED	Double	20	50
	King	20	50

Warning




- Use caution when operating, always use the handle when lifting.
- Note: This bed uses a pressurised mechanism.
- To be operated by adults only
- Please ensure that children and pets are kept away from the bed when operating the lift mechanism.
- Keep children and pets away from the storage area.
- Do not overload the internal storage base.
- Do not stand inside the internal storage area of the bed.
- Before removing the mattress secure the frame to ensure it does not open unexpectedly.
- Do not attempt to lay on the mattress when the ottoman is in the raised position.

 • **Fully Open Ottoman:** Ensure the ottoman is fully open before accessing the storage area.
• **Avoid Hinge Area:** Do not reach into the storage area through the hinge mechanism.
• **Keep Children and Pets Away:** Ensure children and pets stay away from the storage area. Do not stand inside the internal storage area of the bed.
• **Maintenance:** Regularly inspect your bed to ensure it is functioning correctly.

 • **Adult Operation Only:** Not recommend for use by under 12 years old. Please note ease of operation is dependent on height and strength of user.
• **Avoid Entrapment:** Always lift the bed with the mattress in place, using the handle to lift and lower the base, keeping clear of the mechanism.



Note: Be very careful what you store under the bed - the top of an item, like a box or a suitcase, must not touch the slats or they may be damaged. Maximum storage height is 250mm.

Ottoman Beds - Important Safety Features

Our aim is always to give you the best experience and to ensure every effort has been made to guarantee your comfort and safety. Please take time to look at these instructions as they will help remind you how to operate your ottoman bed safely.


Here's a few things you need to remember;

- ✓ **Pistons are already shown in their correct orientation – this improves piston performance and durability.**
- ✓ **“Break in” the piston seals on first use by raising & lowering the platform at least five times.**
- ✓ **Recommended mattress weights - do not exceed the maximum relevant weight specified on the Assembly Instruction.**
- ✓ **Ottoman support bar – always engage the support bar when accessing the ottoman storage area**

Read all the instructions before using your Ottoman bed-frame and save the instruction booklet for future reference.



Ottoman Support Bar (O.S.B.)

For optimal safety during operation, always ensure the O.S.B. is engaged when accessing the ottoman storage area.






1. Always raise the ottoman slat-frame to it's highest position before using the storage area.
Locate the end of the O.S.B and insert into the fixed retaining bracket on the bed frame.
2. When you are ready to lower the ottoman platform, return the O.S.B to its original parking position.
3. Always ensure that the O.S.B is in position when the ottoman is open, this prevents injury, or damage to the product.











Location of the O.S.B






WARNING! Risk of Entrapment

- The pistons on the ottoman bed frame can support a maximum load (evenly spread) as indicated in the Minimum and Maximum load table shown in the main Assembly Instruction.
- Overloading the sleeping platform may contribute to damage to the product resulting in potential serious injury.
- Do not sit on the mattress whilst the platform is in motion or is in the raised position.
- Users should only get in and out of bed when platform is in the flat (horizontal) position.






Components Packed in carton 1	Components Packed in carton 2	
(1) Headboard x1 	(3) Side Rail - Left x1 	(4) Side Rail - Right x1 

Components Packed in carton 3			
(2) Footboard x1 	(5) Side Rail Cross Bar x1 	(6) Gas-lift Mechanism x1 - Left 	(7) Gas-lift Mechanism x1 - Right 
(8) Gas Lift Mechanism - Spacer x2 	(9) Gas-lift Piston x2 	(10) Angled Corner Bracket x2 	(11) 'L' Shape Bracket x2 
(12) Mattress Stopper x2 	(13) Fabric Lifting Strap x1 	(14) Fabric Base Cover x1 	(15) Metal Slat Frame x1 


O.S.B INSTALLATION KIT		
(16) Fixed Retaining Bracket x1 	(17) Parking Bracket x1 	(18) Ottoman Support Bar x1 


HARDWARE FOR ASSEMBLY IS PACKED IN CARTON 3

HARDWARE FOR ASSEMBLING THE BED

A x2  Bolt M8x60mm	B x6  Bolt M8x50mm	C x8  Bolt M8x35mm	D x47  Bolt M8x25mm	E x4  Flanged Lock-Nut M8
F x6  Nut For M8	G x6  Spring Washer For M8 Bolts	H x6  Flat Washer For M8 Bolts	I x2  Corner Hook - Left	J x2  Corner Hook - Right
K x1  Allen Key For M8 Bolts	L x1  Spanner For M8 Nuts	M x2  Metal Connection Plates for Slat Frame	N x1  Remote Control	


Step 1

D  x12 I  x2 J  x2 K  x1




Step 2

D  x12 K  x1






Step 3

D  x4 K  x1




Step 4


D  x8 K  x1



Make certain the bed is squared up as shown in the diagram then tighten all bed assembly bolts 100%.


Step 5

D  x4 K  x1




Step 6





C  x8 K  x1



Step 7



Step 8







Step 9


E  x2 L  x1




Slide gas-lift piston stem (x) onto the axle (y) then fit the flanged lock-nut (E). Tighten nut with spanner - please do not over-tighten

A small gap must be left so stem can move freely - this is important, see sketch below.



Step 10



B  x6 F  x6 G  x6 H  x6
K  x1 L  x1



Loosely fit three bolt sets on each side (B, H, G, F), carefully hold frame down and align so there even gaps at each side, then tighten all bolts 100%.

E x2 L x1


A small gap must be left so stem can move freely -this is important, see sketch below.



A x2 D x3 K x1



Step 13

Set the inner stem of the support bar (18), adjusting the inner stem to the correct length.



Step 14

Fit left or right as preferred. Plug into a 5V power supply (NOT SUPPLIED)



Mini controller



Light mode switching
ON/OFF
Music Mode

Remote Control for RGB IC LED Strip - note this strip meets all the regulations for use in the UK

N 2.4G music controller S 9 RGB Colors 	Turn Off	Auto	Turn On
		Music Activation Mode	
		Timing Off Mode	
	Increase/Decrease Speed	Dynamic Mode	Brightness Adjustment
	Caution The light strip may become warm to the touch when left switched on for more than 2 hrs use, This is perfectly normal.		

Technical Specifications

Overall Dimensions (LWH mm)

Double: 2070 x 1550 x 1050

King: 2170 x 1700 x 1050

Storage Dimensions (LWH mm)

Double: 1930 x 1375 x 250

King: 2030 x 1525 x 250

Ottoman Piston Strength

Double&King: 800N

Distance between slats (mm)


Double: 70

King: 68

Slat Dimension (mm)

Double: 670 x 53 x 9.5

King: 745 x 53 x 9.5



FOR PARTS & TECHNICAL SUPPORT VISIT:

Telephone:

01924950108

Email Address:

support@bedkingdom.co.uk

Manufacturer

Flair Furnishings Ltd t/a Bedkingdom,

Old Delivery Office, Oldfield Lane,

Heckmondwike, England, WF16 0JD

support@bedkingdom.co.uk

01924 950108

EU Responsible (for authorities only)

eucomply Oü

Parnu mnt 139b-14

11317 Tallinn, Estonia

hello@eucompliancepartner.com

+3375690241